

Step 1



Remove the male end of the clip.

Step 3



Insert the cover loop into the opening.

Step 2



Use clippers to make two small, diagonal cuts on the clip.

Step 4



Push the cover loop entirely into the clip.